



MOBILE HOTSPOT

The Details:

- Hotspots provide fast and reliable 4G Internet service.
- One hotspot can connect up to 10 devices (phones, laptops, tablets, printers, cameras, etc.) at the same time.
- Hotspots may be checked out for 14 days.
- Hotspots may be returned to any Osceola Library System location.
- Hotspots may not be renewed – when returned, if no one is waiting, check it out again for another 14 days.
- One hotspot per patron at a time.
- No late fees!
- Hotspots are checked out with the hotspot, a USB charger with a cube, and a carry case.
- A \$100 replacement fee will be charged for a lost or damaged hotspot, \$10 for a lost or damaged charger/cube, \$5 for a lost or damaged case.
- Hotspot service is turned off the first day it is overdue and will not access the Internet until the hotspot is returned.
- Hotspots may not be used outside of the United States.

211 East Dakin Avenue, Kissimmee, FL 34741

407.742.8888 osceolalibrary.org



MOBILE HOTSPOT INSTRUCTIONS

Connecting Your Device:

1. Press & hold OFF/ON button for 2 seconds until all green lights appear.
2. Make sure WiFi is enabled on the device you want to connect to (laptop, cell phone, tablet, etc).
3. Go to your device's WiFi settings and locate the hotspot network: CoolpadSurf_4806
4. Enter the hotspot's password (found below).
5. Once connected, your device is now using the Internet made available by the hotspot connection. Up to 10 devices may connect at the same time using steps 2-4.
6. To turn off the hotspot, press and hold the OFF/ON button for a few seconds.
7. To charge the hotspot, plug in the USB charger (using the cube) to an outlet and plug the smaller end into the hotspot. Or, plug the USB charger into a computer and the smaller end into the hotspot.
8. If you experience any technical issues with the hotspot, call the Library at 407-742-8888 or visit the nearest branch location.

Service/Signal Color:

Red = no service

Yellow = some service

Green = full service

Password	Hotspot ID
40744806	4806